

SPECIFICATIONS

Max power output:	1.7 watts
Max sound output:	98 dB at 1m
Batteries:	4 x AA alkaline non-rechargeable
Water Resistance:	IP65
Temperature range:	-20C to +55C
Battery life:	30-60 days

DECLARATION OF CONFORMITY

QTIME Ltd declare that the product: Model: Tweet is in conformity with the provisions of the following EU directive: Electromagnetic Compatibility Regulations 2014/30/. EN 61000-6-3:2007 Electromagnetic compatibility (EMC) - Part 6-3: Generic standards - Emission standard for residential, commercial and light- industrial environments. EN 61000-6-1:2007 Electromagnetic compatibility (EMC) - Part 6-1: Generic standards - Immunity for residential, commercial and light-industrial environments. Restriction of Hazardous Substances Directive 2011/65/EU. EN 50581 Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances. This declaration of conformity is issued under the sole responsibility of the manufacturer.

Tweet complies with Part 15 of the FCC Rules and Regulations for Information Technology Equipment. Operation is subject to the following two conditions: (1) these devices may not cause harmful interference, and (2) these devices must accept any interference received, including interference that may cause undesired operation.

FD Responsible Party: Qtime Ltd, 1001 Fischer Blvd. Ste 3 PMB 1006. Toms River, NJ 08753-3818 USA

Contact Person: Keith Potter Contact Email: keith.potter@getqtime.com

Equipment Class: FCC Part 15 Class B Product Type: Bird Scarer

We, the responsible party Qtime Ltd, declare that the product Tweet was tested to conform to the applicable FCC rules and regulations. The method of testing was in accordance with the appropriate measurement standards, and all necessary steps have been taken to ensure that all production units of these devices will continue to comply with the Federal Communications Commission's requirements.

K A Potter

Keith Potter. Director Qtime Ltd. 10th January 2024



HOW TWEET WORKS

- Tweet will attract birds looking for a nest site by playing naturally recorded bird calls for 2 hours after dawn.
- Tweet comes in four models for Swifts, House Martins, Sand Martins (Europe) ,and Purple Martins (US and Canada)
- The birds search out nesting sites from spring to early summer. The Tweet calls encourage scouting birds to investigate.
- Swift “Duet Calls” indicate to a potential nesting bird that the site is safe from predators.
- The Tweet device sleeps between bird calls saving battery power.
- Tweet is fully waterproof.

Qtime Ltd. Unit 2. 6 Temple Street. Sidmouth. Devon. EX1 9AY UK

1001 Fischer Blvd. Ste 3 PMB 1006. Toms River, NJ 08753-3818 USA

www.tweetbird.com Contact: info@tweetbird.com

GETTING STARTED

- Fix the supplied green button on a vertical surface near the nesting box and hook the unit on the button. (see video at www.tweetbird.com) Batteries are already inside.
- When it's dark and after dusk, press the power button.
- The red led will light, then the unit will play an initial bird call, then an owl if its dark. That's all you need to do as the device will wake up automatically at dawn. If you hear a cockerel, then it's still too light. Leave the unit switched off for at least five minutes and try again when darker.
- Thereafter, Tweetet will play calls for two hours after dawn.
- Pressing the volume button for more than 2 seconds will adjust the sound output level. The highest tone is the loudest.
- We recommend the unit is dry-stored out of nesting season.

BATTERY REPLACEMENT

- The unit will play a warning message if the battery is getting low or you may notice the bird calls start to appear distorted.
- Depending on the hours of daylight, temperature and volume, the batteries will last around 30 to 60 days.
- To replace, first turn the unit off. Then unscrew the four Philips screws on the front of the unit and keep safe.
- Replace the **4 x AA** alkaline batteries.
- Ensure the white seal on the lid is fully home in its slot .
- Screw the four Philips screws back into the unit. The screws need to be tightened quite firmly. Take care not to trap any wires.

CHANGING THE VOLUME

Tweetet will play the bird calls around the same volume as the actual bird call. Press and hold the volume button for more than 2 seconds to adjust. The highest tone played is the loudest. The unit will store its volume setting if the batteries are changed.

ALL DAY MODE

Tweetet will automatically by default turn off at night and come on at dawn the following morning for two hours.

To enable continuous operation in daylight: Turn the unit off for at least 2 minutes and turn on whilst holding down the volume button and then release after the initial blue tit call play has finished. If it is light and in All Day Mode, two cockerel calls will be heard. If it is still too dark, two owl sounds will be heard. To return to normal default operation, repeat the above to hear a single cockerel sound or owl sound to confirm in default 2 hour mode. The unit will remember the setting if the unit power is turned off.

Note that in All Day Mode, batteries will last around 160 hours.

TROUBLE SHOOTING

- **No sounds at all and flashing red LED:** the unit has an internal error.
 - **Warning message followed by 10 secs of red flashing:** low battery.
 - **Distorted bird songs:** low battery.
 - **No bird calls:** Make sure the unit is in good, external daylight.
 - **Sounding later in day or not a dawn:** Reset the unit, by turning off for a few minutes and turn on after dark
 - If you do have any issues, please email us at info@tweetbird.com
-